

Assembling the Opte Pallet and Corrugated Sleeve

You will need: 2 pallets and 1 corrugated sleeve

1. Place one pallet on the floor.
2. Lift the corrugated sleeve and fold it into a square or rectangle.
 - The first time you do this with a new sleeve, fold it into a near-diamond shape. When you let go, it comes back to its square or rectangle shape.
3. Lift the sleeve over the top of the pallet and place it down into the outer edge of the pallet.
4. Wiggle it until it drops down into the groove that it fits snugly into.
5. Fill the sleeve.
 - Don't fill it all the way to the top. Leave a few inches and make sure the contents are relatively level.
6. Take the other pallet, flip it upside down, then place it on top of the filled sleeve. Once it is lined up squarely, it will drop into the outer edge, just like when you set up the bottom.
7. Repeat steps 1-6 for each container.
8. Use a forklift to pick up each container, then set them on top of each other.
 - The pallets are 48x40 and fit together ONE WAY.
 - You can pick them up from all 4 sides. Just make sure you pick it up from the side that you are coming in.
 - When they are correctly aligned, they will slide down into one another.

