

GIMBAL FOR 700 SERIES YACHT LAMPS

1. Attach gimbal to cabin wall or where required using the three brass screws provided.
2. Loosen bolts (a).
3. Position lamp into gimbal with ring clamp (b) around lamp standard rods (see fig 1).
4. Gently ease the ring clamp (b) upwards and over the lamp's middle ring until it rests below the stops around the top of the ring (see fig 2).
5. Tighten bolts (a) to maximum.
6. The lamp will be held in place by the downward pressure of the stops on the ring clamp (b) and the inward pressure of the tightened bolts (a).

