



One-Component, 100% Solids Adhesive

- Fast, aggressive tack
- Fast-drying
- One-step application
- Reduces installation time and cost
- Can be used for commercial and residential

Resilient flooring has finally met its match. Shaw MS Resilient's safe, 1-part chemistry makes it a faster, more install-friendly alternative to 2-part epoxy systems. Engineered for heavy rolling loads and challenging environments, MS Resilient's waterproof design forms a robust moisture vapor barrier and can also take the punishment introduced by topical liquids.

APPROVED FLOORING TYPES

- LVT/LVP
- Sheet goods (vinyl, homogeneous, fiberglass, felt-backed)
- Rubber tile and sheet
- Linoleum
- WPC/WSC
- Cork-backed hard surface
- Cork flooring
- Cork underlayment
- VCT/VET
- Stair treads (rubber and vinyl)

APPROVED SUBSTRATES & SURFACES

- APA underlayment grade plywood and OSB
- Association grade particleboard
- Cement backer board
- Concrete and radiant heated subfloors that do not exceed 85°F (30°C)
- Existing well-bonded non-cushion-backed vinyl, tile and sheet flooring
- Fully secured cork underlayments
- Gypsum and lightweight concrete (primed with Shaw 9050 primer)
- Terrazzo (properly prepared with all waxes and surface finishes removed)

SUBSTRATE TESTING

- **RH** - No testing required (100%) [ASTM F2170]
- **pH** - No testing required (5-14)
- **MVER** - No testing required [ASTM F1869]

SUBSTRATE PREPARATION

Follow flooring manufacturer's guidelines. Substrate must be prepared per ASTM F710 standards including, but not limited to the following:

- Concrete floors must be dry, clean, smooth and structurally sound. They shall be free of any foreign materials that might prevent adhesive bond, including dust, dirt, solvent, paint, wax, oil, grease, residual adhesive, adhesive removers, incompatible sealers, fire-retardant chemicals, fungicides, release agents, alkaline salts, excessive carbonation, laitance, mold, mildew, and curing, sealing, hardening or parting compounds.
- Fill all surface cracks, grooves, depressions, control joints and non-moving joints with moisture-resistant patching and self-leveling compounds, allow to fully cure and correct high spots before applying adhesive.
- The substrate, adhesive and flooring must be acclimated in an enclosed building with the HVAC operational between 60-95°F (15-35°C), and between 30-65% relative humidity, for at least 72 hours before, during and after the installation.
- When installing over radiant heated subfloors, turn the heat off for 24 hours before, during and after installation. Failure to turn the heat off may result in shortened working time of the adhesive. When turning radiant heat back on, raise it incrementally, not to exceed a change of more than 5 degrees per hour to a maximum of 85°.

PRECAUTIONARY NOTES

- Concrete must be placed in strict accordance with applicable standards and specifications. An intact moisture vapor retarder must be present below the concrete (see ASTM E1745), must be fully cured (at least 45 days) and without hydrostatic pressure.
- Flooring must be acclimated per manufacturer's guidelines.
- When used as a concrete moisture vapor barrier, substrate must be porous per ASTM F3191.

APPLICATION INSTRUCTIONS



- Spread adhesive using required tools (see tool chart below).
 - Adhesive ridges will dissipate, and Shaw MS Resilient adhesive does not require back-rolling under normal circumstances.
- Install flooring per the instructions below dependent upon desired application method.
 - Tile products
 - Wait 10 minutes after adhesive is spread to build surface tack and reduce movement.
 - Working time is approximately 45 min under acceptable temperature and humidity conditions.
 - Use a hand roller and apply normal pressure to ensure a good bond.
 - Periodically lift flooring material to verify proper transfer of adhesive.
 - Sheet goods and stair treads
 - Install flooring or stair treads immediately after adhesive is spread.
 - Working time is approximately 45 min under acceptable temperature and humidity conditions.
 - Periodically lift flooring material to verify proper transfer of adhesive.
- Roll and cross roll floor with a 75-100 lbs (34-45 kg) roller at the end of the installation to ensure proper transfer of adhesive.

APPLICATION INSTRUCTIONS

- Wait 6 hours before heat welding sheet goods.
- Do not wet mop the floor for 6 hours after the install is complete.
- Do not strip and finish the floor for 6 hours after the install is complete.
- Reseal lid when not in use to protect product.

REQUIRED TOOLS AND COVERAGE

Trowel dimensions are width × depth × spacing. Coverage is approximate and may vary depending on porosity of substrate and the angle at which the trowel is held.

Flooring Type	Tool (images not to scale)	Estimated Coverage
LVT/LVP, VCT/VET	$1/16" \times 1/32" \times 1/32"$ (1.6 mm × .8mm × .8mm) U-Notch	 175–225 s.f./gal.
Sheet goods, Rubber tile and sheet, Linoleum, WPC/WSC, Corkbacked hard surface, Cork flooring, Cork underlayment, Stair treads (rubber and vinyl)	$1/16" \times 1/16" \times 1/16"$ (1.6 mm × 1.6mm × 1.6mm) Sq Notch	 140–170 s.f./gal.

It is the sole responsibility of the contractor/installer to determine the proper porosity of the subfloor, apply the proper amount of adhesive for the job conditions and ensure that all instructions, procedures and practices are strictly adhered to.

CLEANING INSTRUCTIONS

While product is still wet: use a damp cloth and water to remove.

While product is still soft: use Shaw adhesive remover/stripper, denatured alcohol or mineral spirits. Always check compatibility on a piece of scrap flooring.

PRODUCT CHARACTERISTICS	Product Classification	Modified urethane (isocyanate free)
	Base Chemistry	STPE polymer-based (Hybrid Propel®)
	Curing Method	Moisture cure
	Appearance	Off white
	Consistency	Smooth, low viscosity liquid
	Application	Easy troweling
	Flammability	Non-flammable
	Freeze/Thaw	Stable to 10° F (-12° C)
	Shelf Life	1 year
MOISTURE	Moisture Control	Protects flooring against unlimited moisture
	RH [ASTM F2170]	No testing required (100%)
	pH	No testing required (5-14)
	MVER [ASTM F1869]	No testing required
TIME	Open Time	0 min. (sheet goods and stair treads); 10 min. (tile products)
	Dry Time	N/A
	Working Time	45 min.
	Cure Time	6 hr.
	Pot Life	N/A
TRAFFIC	Light Traffic	3 hr.
	Heavy Traffic	4 hr.
	Heavy Rolling Loads	8 hr.
SUSTAINABILITY	Solvents	None
	Isocyanates	None
	VOC (g/L) - SCAQMD Rule #1168	0.1
	LEED Points	Contributes to low emitting materials
	Certifications	GreenGuard, FloorScore, CRI Green Label Plus
ACOUSTICS	IIC (Delta)	68 dB (19)
	STC (Delta)	66 dB (19)

*IIC (delta) and STC (delta) ranges are flooring assembly specific based on third-party testing and verification in a controlled environment. For any questions or further information, please contact Shaw Technical Services at (800) 441-7429.

STORAGE

This product should be stored at temperatures between 50-90° F (15-32° C). While this product is freeze-thaw stable, it is necessary to protect it from freezing. Freeze-thaw stable to 10° F (-12° C).

CAUTION

DO NOT take internally. If swallowed, DO NOT induce vomiting. Call a physician immediately. KEEP OUT OF REACH OF CHILDREN.

WARRANTY INFORMATION

This product is manufactured according to exacting quality-control standards and is warranted to be free from manufacturing defects. Defective material called to our attention within one year of manufacture will be replaced. No guarantee, express or implied, is made regarding the performance of this product since the manner and conditions of application are beyond our control. For complete warranty information call Shaw Technical Services at (800) 441-7429. You may also visit us on the web at: www.shawfloors.com.